

## Induction

$$\mathcal{E} = -N \frac{d\Phi_B}{dt}$$

---

---

---

---

---

---

---

---

## Induction

Production of emf due to Changing Flux

$$\mathcal{E} = -N \frac{d\Phi_B}{dt}$$

Faraday's Law

---

---

---

---

---

---

---

---

## Induction

Some applications:

$$\mathcal{E} = -N \frac{d\Phi_B}{dt}$$

- Changing magnitude of field
- Changing size of loop relative to field
- Changing loop direction relative to field
- Conductor moving in field

---

---

---

---

---

---


---

---

Example: A square loop of wire has area vector,  $\vec{A} = L^2 \hat{k}$ , in a region with a magnetic field,  $\vec{B} = B_0 \cos(\omega t) \hat{k}$ .

- Changing magnitude of field

$$\mathcal{E} = -N \frac{d\Phi_B}{dt}$$



How could you create a spatially uniform magnetic field that changed as a function of time?

---

---

---

---

---

---


---

---

Example: A square loop of wire has area vector,  $\vec{A} = L^2 \hat{k}$ , in a region with a magnetic field,  $\vec{B} = B_0 \cos(\omega t) \hat{k}$ .

- Changing magnitude of field

$$\mathcal{E} = -N \frac{d\Phi_B}{dt}$$



How could you create a spatially uniform magnetic field that changed as a function of time?

---

---

---

---

---

---


---

---

Example: A square loop of wire has area vector,  $\vec{A} = L^2 \hat{k}$ , in a region with a magnetic field,  $\vec{B} = B_0 \cos(\omega t) \hat{k}$ .

- Changing magnitude of field

$$\mathcal{E} = -N \frac{d\Phi_B}{dt}$$



How could you create a spatially uniform magnetic field that changed as a function of time?

---

---

---

---

---

---

---

---

Induction

- Changing magnitude of field  $\mathcal{E} = -N \frac{d\Phi_B}{dt}$

Solenoid

Loop

Could change location of loop relative to source of magnetic field by moving loop.

---

---

---

---

---

---

---

---

Induction

- Changing magnitude of field  $\mathcal{E} = -N \frac{d\Phi_B}{dt}$

Solenoid

Loop

Could change location of loop relative to source of magnetic field by moving field.

---

---

---

---

---

---

---

---

Example: A conducting bar is slid along a U-shaped conductor such that the formed loop has an area vector parallel to a uniform magnetic field in the region.

- Changing size of loop relative to field  $\mathcal{E} = -N \frac{d\Phi_B}{dt}$

$\vec{B}$

$\vec{v}$

L

---

---

---

---

---

---


---

---

Example: A square conducting loop is moved into a region of uniform magnetic field such that the loop's area vector is parallel to the magnetic field.

- Changing size of loop relative to field

$$\mathcal{E} = -N \frac{d\Phi_B}{dt}$$




---

---

---

---

---

---


---

---

Example: A square conducting loop is rotated in a region with a uniform magnetic field.

- Changing loop direction relative to field

$$\mathcal{E} = -N \frac{d\Phi_B}{dt}$$




---

---

---

---

---

---


---

---

Example: A conducting rod is moved through a region of uniform magnetic field. [An induction problem, but not a changing flux problem]

- Conductor moving in field

$$\mathcal{E} = -N \frac{d\Phi_B}{dt}$$




---

---

---

---

---

---

---

---